

Antique Door Bell:

1. Drill a $\frac{3}{4}$ " diameter by 1" deep hole in desired position for door bell.
2. Fasten wires in terminals provided.
3. Mount door bell, fastening screws provided.

Directions are for guidance only. Requirements may vary due to individual circumstances. We recommend drilling smaller pilot holes before screwing to reduce the chance of splitting wood, and when going completely through wood products, drill from both sides.