

## Auto Lock Animal Bolt:

1. Position bolt assembly on door/gate. Secure with screws provided.
2. Ensuring that the bolt is in the engaged position, align the staple on the door/gate frame. Mark holes and secure staple with screws provided.
3. With bolt still in engaged position and locking latch in locked position, place lock shield  $\frac{3}{4}$ " below the locking mechanism. Mark and drill holes and secure with screws provided.

Directions are for guidance only. Requirements may vary due to individual circumstances. We recommend drilling smaller pilot holes before screwing to reduce the chance of splitting wood, and when going completely through wood products, drill from both sides.