

Curved Rail Hinge:

1. Place the hinges onto the door/gate in the desired positions adjusting the overhang of the pins so they are central on the post or door frame. Pivot the bands so they are central on the rail of the gate. Drill $\frac{1}{2}$ " holes and fix with the bolts provided.
2. Place the door/gate into position and support allowing correct clearances between the post/frame.
3. Place the cups onto the pins and fasten the cups to the post or door frame with the screws provided.
4. May grease for smooth operation.

Directions are for guidance only. Requirements may vary due to individual circumstances. We recommend drilling smaller pilot holes before screwing to reduce the chance of splitting wood, and when going completely through wood products, drill from both sides.